



Schnieder
AUTOTECH
ORIGINAL



2
0
2
3

**EUROPEAN CATALOGUE
BRAKE WEAR SENSORS**

PKW

Manufacture To Last

BMW

MERCEDES

AUDI

RANGE ROVER

VOLVO

OPEL

MINI COOPER

JAGUAR

BENTLEY

LAND ROVER

PORSCHE

VOLKSWAGEN

SEAT



www.schniederautotech.com

ADDRESS : Norwig Verwaltungs GmbH
Strausberger Platz 13
10243 Berlin, Germany

PHONE : +49-(0)30-84711199

E-MAIL : info@schniederautotech.com



Reliable Quality

MERCEDES

BRAKE WEAR SENSORS

PAGE - 4 - 8

BMW

BRAKE WEAR SENSORS

PAGE - 9 - 19

**VW
AUDI**

BRAKE WEAR SENSORS

PAGE - 20 - 22

PORSCHE

BRAKE WEAR SENSORS

PAGE - 23 - 25

LR / RR

BRAKE WEAR SENSORS

PAGE - 26 - 29

JAGUAR

BRAKE WEAR SENSORS

PAGE - 30 - 31



BRAKE WEAR SENSORS

ITEM NO	DESCRIPTION	PART NO	PICTURE
BZS88.00160	Brake Wear Sensor W211/ W220	211 540 17 17 220 540 06 17 220 540 07 17	
BZS88.00175	Brake Wear Sensor FR W220/W164 [620425]	164 540 10 17 220 540 15 17	
BZS88.00176	Brake Wear Sensor FR W204/212/221/166 [620420]	171 540 06 17	
BZS88.00187	Brake Wear Sensor Sprinter RR [L+R] [06-15]	906 540 13 17	
BZS88.00188	Brake Wear Sensor FR Sprinter [L+R] 06-15 [620424]	906 540 14 17 906 540 15 17	

BRAKE WEAR SENSORS

ITEM NO	DESCRIPTION	PART NO	PICTURE
BZS88.00189	Brake Wear Sensor [126 540 20 17] W124 E-CLASS	140 540 12 17	
BZS88.00196	Brake Wear Sensor FR E463/Sprinter [620407]	901 540 00 17 901 540 01 17	
BZS88.00197	Brake Wear Sensor FR Sprinter [620417]	901 540 02 17 901 540 03 17	
BZS88.00210	Brake Wear Sensor W123	123 540 00 17	
BZS88.00211	Brake Wear Sensor FR W163 [620412]	163 540 15 17 163 540 17 17	

BRAKE WEAR SENSORS

ITEM NO	DESCRIPTION	PART NO	PICTURE
BZS88.00189	Brake Wear Sensor [126 540 20 17] W124 E-CLASS	140 540 12 17	
BZS88.00196	Brake Wear Sensor FR E463/Sprinter [620407]	901 540 00 17 901 540 01 17	
BZS88.00197	Brake Wear Sensor FR Sprinter [620417]	901 540 02 17 901 540 03 17	
BZS88.00210	Brake Wear Sensor W123	123 540 00 17	
BZS88.00211	Brake Wear Sensor FR W163 [620412]	163 540 15 17 163 540 17 17	

BRAKE WEAR SENSORS






ITEM NO	DESCRIPTION	PART NO	PICTURE
BZS88.00212	Brake Wear Sensor RR W163 ML	163 540 14 17	
BZS88.00213	Brake Wear Sensor FR W163 ML	163 540 13 17	
BZS88.00214	Brake Wear Sensor W210	210 540 11 17	
BZS88.00215	Brake Wear Sensor W126	126 540 20 17	
BZS88.00216	Brake Wear Sensor W201	201 540 03 17	

BRAKE WEAR SENSORS

ITEM NO	DESCRIPTION	PART NO	PICTURE
BZS88.00217	Brake Wear Sensor FR W220/W463	202 540 07 17	
BZS88.00218	Brake Wear Sensor W211	211 540 07 17	
BZS88.00283	Brake Wear Sensor W222 6/8-Cyl [13-19] [620959]	231 905 00 14	
BZS88.00289	Brake Wear Sensor FR W205/W176/X156/X253 [12-18] [620067] [92,5 mm]	169 540 16 17	

BRAKE WEAR SENSORS

BMW

ITEM NO	DESCRIPTION	PART NO	PICTURE
BMS88.00153	Brake Wear Sensor FR X1-E84 [09-15] [620297]	34 35 6 792 562	
BMS88.00169	Brake Wear Sensor FR F01 740i [620260]	34 35 6 775 850	
BMS88.00170	Brake Wear Sensor FR F10/F01 [620298]	34 35 6 791 958	
BMS88.00171	Brake Wear Sensor RR E60 [620274]	34 35 6 759 918 34 35 6 764 299 34 35 6 768 596 34 35 6 774 422 34 35 6 776 422 34 35 6 789 493	
BMS88.00172	Brake Wear Sensor RR F01 [620261]	34 35 6 775 858	

BRAKE WEAR SENSORS

ITEM NO	DESCRIPTION	PART NO	PICTURE
BMS88.00174	Brake Wear Sensor RR E90 [620265]	34 35 6 762 253 34 35 6 789 445	
BMS88.00177	Brake Wear Sensor FR X5/ X6 6-Cyl [620268]	34 35 6 772 008 34 35 6 789 501	
BMS88.00178	Brake Wear Sensor RR E65 [620231]	34 35 6 755 267 34 35 6 778 038	
BMS88.00179	Brake Wear Sensor FR E65 [620230]	34 35 6 755 266 34 35 6 778 037	
BMS88.00180	Brake Wear Sensor RR X5/ X6 [3.0/4.8] [620269]	34 35 6 771 766 34 35 6 780 699 35 35 6 789 505	

BRAKE WEAR SENSORS

BMW

ITEM NO	DESCRIPTION	PART NO	PICTURE
BMS88.00181	Brake Wear Sensor FR X5/ X6 4.8 [620291]	34 35 6 792 568	
BMS88.00182	Brake Wear Sensor FR X5/ X6 4.8 [620071]	34 35 6 792 569 34 35 6 860 181	
BMS88.00183	Brake Wear Sensor RR F01 [620299]	34 35 6 791 960	
BMS88.00184	Brake Wear Sensor FR X5/ X6 [620281]	34 35 6 789 080	
BMS88.00191	Brake Wear Sensor FR X3- E83 [06-10] [620240]	34 35 3 411 756	

BRAKE WEAR SENSORS

BMW

ITEM NO	DESCRIPTION	PART NO	PICTURE
BMS88.00192	Brake Wear Sensor RR X3-E83 [06-10] [620241]	34 35 3 411 757	
BMS88.00194	Brake Wear Sensor E60 FR [620273]	34 35 6 764 298 34 35 6 768 595 34 35 6 776 421 34 35 6 789 492	
BMS88.00195	Brake Wear Sensor FR E90 [620264]	34 35 6 762 252 34 35 6 789 439	
BMS88.00219	Brake Wear Sensor RR E90 [620285]	34 35 6 792 564	
BMS88.00220	Brake Wear Sensor RR X5/X6 [08-17] [620028]	34 35 6 854 168	

BRAKE WEAR SENSORS

BMW

ITEM NO	DESCRIPTION	PART NO	PICTURE
BMS88.00221	Brake Wear Sensor RR E36 [620211]	34 35 1 182 533	
BMS88.00222	Brake Wear Sensor RR E39 Estate [620222]	34 35 1 163 207	
BMS88.00223	Brake Wear Sensor FR X5/ X6 [620289]	34 35 6 792 567	
BMS88.00224	Brake Wear Sensor FR X5/ X6 E70 X5 [3.0/4.8] [620270]	34 35 6 773 008 34 35 6 789 502	
BMS88.00225	Brake Wear Sensor X6 E70 [620280] FR+RR	34 35 6 780 698 34 35 6 789 503	

BRAKE WEAR SENSORS

BMW






ITEM NO	DESCRIPTION	PART NO	PICTURE
BMS88.00226	Brake Wear Sensor RR X5/ X6 E70 [620290]	34 35 6 792 571	
BMS88.00227	Brake Wear Sensor FR E39 [620219]	34 35 1 163 065 34 35 2 229 018	
BMS88.00228	Brake Wear Sensor RR E39 [620218]	34 35 1 163 066	
BMS88.00229	Brake Wear Sensor FR E46 [620220]	34 35 1 164 371	
BMS88.00230	Brake Wear Sensor RR E46 [620221]	34 35 1 164 372	

BRAKE WEAR SENSORS

BMW






ITEM NO	DESCRIPTION	PART NO	PICTURE
BMS88.00231	Brake Wear Sensor FR E53/ X5 [620225]	34 35 1 165 579	
BMS88.00232	Brake Wear Sensor RR E53/ X5 [620226]	34 35 1 165 580	
BMS88.00233	Brake Wear Sensor E34 [620214] FR+RR	34 11 2 225 107 34 35 1 179 820 34 35 1 180 432 34 35 1 180 781	
BMS88.00234	Brake Wear Sensor E30 [620213] FR+RR	34 11 1 152 607 34 35 1 179 819 34 35 1 180 782	
BMS88.00235	Brake Wear Sensor FR E36 [620207]	34 35 1 181 337 34 35 1 181 338	

BRAKE WEAR SENSORS

ITEM NO	DESCRIPTION	PART NO	PICTURE
BMS88.00236	Brake Wear Sensor RR E36 [620206]	34 35 1 181 342 34 35 1 181 344	
BMS88.00237	Brake Wear Sensor RR E38 [620209]	34 35 1 182 064 34 35 6 751 311 34 35 2 283 335 34 35 2 283 405 34 35 1 182 065 34 35 2 229 780	
BMS88.00238	Brake Wear Sensor FR E90 [04-11] [620267]	34 35 6 777 649 34 35 6 779 619 34 35 6 789 440	
BMS88.00239	Brake Wear Sensor RR F10 [620312]	34 35 6 791 962	
BMS88.00240	Brake Wear Sensor RR F11 [620308]	34 35 6 791 963	

BRAKE WEAR SENSORS

BMW

ITEM NO	DESCRIPTION	PART NO	PICTURE
BMS88.00241	Brake Wear Sensor FR F30 [620006]	34 35 6 792 289	
BMS88.00242	Brake Wear Sensor RR F30 [316i/318i/320i/328i/330i/335i/340i] [620007] [1,045 mm]	34 35 6 792 292	
BMS88.00243	Brake Wear Sensor Mini R60	34 35 9 804 833	
BMS88.00244	Brake Wear Sensor Mini R60	34 35 9 804 834	
BMS88.00245	Brake Wear Sensor RR X5/ X6 [3.0/4.8] [620269]	34 35 6 789 505	

BRAKE WEAR SENSORS

BMW

ITEM NO	DESCRIPTION	PART NO	PICTURE
BMS88.00276	Brake Wear Sensor G30/ F90/G11 [4/6-Cyl] [15-19]	34 35 6 861 807	
BMS88.00281	Brake Wear Sensor FR X3/ X4 [620309]	34 35 6 790 303	
BMS88.00282	Brake Wear Sensor RR X3/ X4 [620310]	34 35 6 790 304	
BMS88.00287	Brake Wear Sensor RR G30/ F90/G11 [4/6-Cyl] [16-19]	34 35 6 861 808 34 35 6 890 791	
BMS88.00288	Brake Wear Sensor RR X1- E84 [09-15] [620296]	34 35 6 792 565	

BRAKE WEAR SENSORS

BMW

ITEM NO	DESCRIPTION	PART NO	PICTURE
BMS88.00276	Brake Wear Sensor G30/ F90/G11 [4/6-Cyl] [15-19]	34 35 6 861 807	
BMS88.00281	Brake Wear Sensor FR X3/ X4 [620309]	34 35 6 790 303	
BMS88.00282	Brake Wear Sensor RR X3/ X4 [620310]	34 35 6 790 304	
BMS88.00287	Brake Wear Sensor RR G30/ F90/G11 [4/6-Cyl] [16-19]	34 35 6 861 808 34 35 6 890 791	
BMS88.00288	Brake Wear Sensor RR X1- E84 [09-15] [620296]	34 35 6 792 565	

BRAKE WEAR SENSORS

ITEM NO	DESCRIPTION	PART NO	PICTURE
VAS88.00161	Brake Wear Sensor FR Q7/ Cayenne/Touareg 3.6/4.2/4.8 [420 mm]	7L0 907 637	
VAS88.00162	Brake Wear Sensor FR Q7/ Cayenne/Touareg 3.6/4.2/4.8 [255 mm]	7L0 907 637 C	
VAS88.00163	Brake Wear Sensor FR Touareg/Cayenne/ Panamera [3.6/4.2/4.8] [10-18]	7P0 907 637	
VAS88.00164	Brake Wear Sensor RR Touareg/Cayenne/ Panamera [3.6/4.2/4.8] [10-18]	7P0 907 637 C	
VAS88.00202	Brake Wear Sensor FR A6/ A7 2.0/2.8/3.0 [10-18] [330mm]	4G0 615 121 D	



VW/AUDI

BRAKE WEAR SENSORS

ITEM NO	DESCRIPTION	PART NO	PICTURE
VAS88.00207	Brake Wear Sensor FR A8/ A6/A7 [11-16] 312mm [620301]	4H0 615 121 J	
VAS88.00208	Brake Wear Sensor RR A8/ A6/A7 [11-16] 250mm	4H0 615 121 H	
VAS88.00209	Brake Wear Sensor RR A6/ A7 2.0/2.8/3.0 [10-18] 217mm [620313]	4G0 615 121	
VAS88.00261	Brake Wear Sensor FR A7/ Q5 1.8/2.0/3.0 TFSI [10-18] [620068]	8R0 615 121 A	
VAS88.00334	Brake Wear Sensor FR A4/ A5/A7/Q8 [2.0/3.0] [15-18]	4M0 615 121 AB	

VW/AUDI

BRAKE WEAR SENSORS

ITEM NO	DESCRIPTION	PART NO	PICTURE
VAS88.00335	Brake Wear Sensor RR A4/ A5/A7/Q8 [2.0/3.0] [15-18] [379 mm]	4M0 615 121 P	
VAS88.00336	Brake Wear Sensor FR A4/ A5/A7/Q8 [2.0/3.0] [15-18] [394 mm]	8W0 615 121 E	

VW/AUDI

BRAKE WEAR SENSORS

ITEM NO	DESCRIPTION	PART NO	PICTURE
PRS88.00248	Brake Wear Sensor FR Cayenne 3.2/3.6/4.5/4.8 Turbo [620066]	955 612 365 50	
PRS88.00249	Brake Wear Sensor FR Cayenne/Panamera 3.0/3.6/4.2/4.8 [620939]	970 609 143 00	
PRS88.00250	Brake Wear Sensor RR Cayenne/Panamera 3.0/3.6/4.2/4.8 [620940]	970 609 145 00	
PRS88.00251	Brake Wear Sensor RR Cayman/Boxter 2.7/2.9 [620932]	987 612 676 01	
PRS88.00252	Brake Wear Sensor FR Carrera/Cayman 3.6/3.8 [620957]	997 612 675 01	




PORSCHE

BRAKE WEAR SENSORS

ITEM NO	DESCRIPTION	PART NO	PICTURE
PRS88.00253	Brake Wear Sensor FR Carrera S, 4, 4S [620956]	997 612 679 00	
PRS88.00254	Brake Wear Sensor FR Carrera 4S, GTS [620950]	997 612 680 00	
PRS88.00255	Brake Wear Sensor Porsche Boxter , Cayman	997 612 755 00	
PRS88.00256	Brake Wear Sensor Porsche Boxter, Cayman	997 612 756 00	
PRS88.00257	Brake Wear Sensor Porsche Boxter, Cayman, Carrera	997 612 759 00	

PORSCHE

BRAKE WEAR SENSORS

ITEM NO	DESCRIPTION	PART NO	PICTURE
PRS88.00258	Brake Wear Sensor Porsche Carrera 4	997 612 769 00	
PRS88.00259	Brake Wear Sensor Porsche Carrera	997 612 770 00	
PRS88.00337	Brake Wear Sensor FR Macan 2.0/3.0/3.6 10-18 [353 mm]	95B 907 2!	

PORSCHE

BRAKE WEAR SENSORS

ITEM NO	DESCRIPTION	PART NO	PICTURE
LRS88.00124	Brake Wear Sensor FR Discovery IV [L319] [09-14] [620946]	SEM500070	
LRS88.00125	Brake Wear Sensor Discovery-III 05-09	SEM000024	
LRS88.00126	Brake Wear Sensor Range Rover 02-09	SEM000012	
LRS88.00127	Brake Wear Sensor R-Rover III 4.2 02-09 [620944]	SEM500050	
LRS88.00128	Brake Wear Sensor RR R-Rover III [L322] [05-12] [621308]	SOE000011	

RR/LR

BRAKE WEAR SENSORS

ITEM NO	DESCRIPTION	PART NO	PICTURE
LRS88.00129	Brake Wear Sensor FR R-Rover Sport 05-09 [620948]	SEM500026	
LRS88.00130	Brake Wear Sensor R-Rover 02-09	SOE500030	
LRS88.00131	Brake Wear Sensor R-Rover Sport 05-09	SEM500062	
LRS88.00132	Brake Wear Sensor R-Rover Sport 05-09	SEM500080	
LRS88.00133	Brake Wear Sensor FR R-Rover Sport 05-09 [620948]	SEM500090	

RR/LR

BRAKE WEAR SENSORS

ITEM NO	DESCRIPTION	PART NO	PICTURE
LRS88.00134	Brake Wear Sensor RRover Sport 2010	LR019401	
LRS88.00135	Brake Wear Sensor RR R-Rover Sports 05-09 [621306]	SOE000025	
LRS88.00173	Brake Wear Sensor RR R-Rover IV/Sport [L405/L494] 4.4/5.0 [12-18] [951 mm]	LR033295	
LRS88.00190	Brake Wear Sensor FR R-Rover IV/Sport [L405/L494] 4.4/5.0 [12-18] [1424 mm]	LR033275	
LRS88.00193	Brake Wear Sensor FR R-Rover Sport [L494] 13-14	LR045959	

RR/LR

BRAKE WEAR SENSORS

ITEM NO	DESCRIPTION	PART NO	PICTURE
LRS88.00260	Brake Wear Sensor RR Discovery/Sport 15-Up 2.0D	LR061394 LR072544	
LRS88.00264	Brake Wear Sensor FR Axle L+R R-Rover III/Sport [L322] 5.0 [09-12]	LR012824	
LRS88.00275	Brake Wear Sensor Evoque L538 [2.0/2.2D 4X4] 11-15	LR072017	
LRS88.00278	Brake Wear Sensor RR R-Rover VELAR [L560] [17-19]	LR090709	
LRS88.00309	ABS Wheel Speed Sensor Evoque/Discovery Sport [L550/L538] 2.0 4x4 FR L+R [1190mm]	LR061365	

RR/LR

BRAKE WEAR SENSORS

ITEM NO	DESCRIPTION	PART NO	PICTURE
JRS88.00185	Brake Wear Sensor FR XF/ XJ 2.0/3.0/4.2/5.0 [590mm] [P8638]	C2P17004	
JRS88.00186	Brake Wear Sensor RR XF/ XJ 2.0/3.0/4.2/5.0 [635mm] [P8639]	C2D2976	
JRS88.00199	Brake Wear Sensor FR XJ 5.0 V8 [550mm]	C2P12722	
JRS88.00277	Brake Wear Sensor FR F- Pace [X761] [15-19]	T4A12867	
JRS88.00278	Brake Wear Sensor RR F- Pace [X761] [15-19]	T4A3216	

JAGUAR

BRAKE WEAR SENSORS

ITEM NO	DESCRIPTION	PART NO	PICTURE
JRS88.00318	Brake Wear Sensor FR Axle L+R XF 3.0 08-15 [610mm]	C2Z16061	